

## INSTALLATION GUIDE

- 1 --- For against wall application, position the collection tray to allow for combined thickness of the tile substrate plus tile (see cross section).
- 2 --- For other than against wall installation snap off and remove the vertical SWDVG from the collection tray.
- 3 --- If needed cut to length the collection tray allowing for end stops and joiners.
- 4 --- Position one or more holes for 40 mm spigots (fits into 50 mm DWV) and drill, take care to remove burrs from holes & cuts.

Glue the parts together using a SWDVG PVC adhesive and test for leaks before SWDVG


Installation to be in compliance with AS 3500.2.

The top of the collection tray flange must be level with the top of the tile substrate.

Provide fall & waterproofing to the tile substrate and waterproof over the collection tray flange

SWDVGUWDDWDGDPRDGERWFWDFWWEFWEFUGUFEUWDV

WVEDVDPPEUUG



## TILING

- 1 --- Cut the tile edging to length allowing for a 5 mm gap all around between the blade and the tile edging.
- 2 --- Position the lengths of tile edging supplied with tiles to suit the tile thickness on the collection tray flange.
- 3 --- **Position the tile edging so that there are equal gaps of 5 mm between the blade and the tile edging.**
- 4 --- After tiling select the appropriate size spacers **D** to align the top of the blade with the top of the tiles.
- 5 --- Use the blade installation tool to locate and to tap the spacers into the slot in bottom of collection channel.
- 6 --- Separate the spacers evenly along the collection channel to support the blade & glue them in position.
- 7 --- Cut the blade to length if necessary, making sure that both ends fit into the end stop blade locating lugs.