


INSTALLATION GUIDE

- 1 --- For against wall application, position the collection tray to allow for combined thickness of the tile substrate plus tile (see cross section).
- 2 --- For other than against wall installation snap off and remove the vertical upstand from the collection tray.
- 3 --- If needed cut to length the collection tray allowing for end stops and joiners.
- 4 --- Position one or more holes for 40 mm spigots , (fits into 50 mm DWV) and drill, take care to remove burrs from holes & cuts.
NB. Glue the parts together using a PVC adhesive and test for leaks before installing.
- 5 --- Installation to be in compliance with AS 3500.2.
- 6 --- The top of the collection tray flange must be level with the top of the tile substrate.
- 7 --- Provide fall & waterproofing to the tile substrate and waterproof over the collection tray flange



TILING

- 1 --- Cut the tile edging to length allowing for a 5 mm gap all around between the blade and the tile edging.
- 2 --- Position the lengths of tile edging supplied with tiles to suit the tile thickness on the collection tray flange.
- 3 --- **Position the tile edging so that there are equal gaps of 5 mm between the blade and the tile edging.**
- 4 --- After tiling select the appropriate size spacers **D** to align the top of the blade with the top of the tiles.
- 5 --- Use the blade installation tool to locate and to tap the spacers into the slot in bottom of collection channel.
- 5--- Separate the spacers evenly along the collection channel to support the blade & glue them in position.
- 7 ... Cut the blade to length if necessary, making sure that both ends fit into the end stop blade locating lugs.